


SHARP SERVICE MANUAL

S3208AFP08CX/



AIR CONDITIONER

MODEL AF-P80CX

In the interests of user-safety (Required by safety regulations in some countries) the set should be restored to its original condition and only parts identical to those specified should be used.

TABLE OF CONTENTS

	Page
SPECIFICATIONS	2
WIRING DIAGRAM	3
EXTERNAL DIMENSIONS	4
HOW TO OPERATE	5
INSTALLATION INSTRUCTIONS	15
DISASSEMBLING PROCEDURE	18
HOW TO REPAIR REFRIGERATION	21
ELECTRICAL COMPONENT TEST	23
MICROCOMPUTER CONTROL SYSTEM	24
TROUBLESHOOTING GUIDE	28
COOLING LOAD ESTIMATE FORM	33
RUNNING CONDITION	35
PACKING AND ACCESSORIES	36
REPLACEMENT PARTS LIST	37

SHARP CORPORATION

This document has been published to be used for after sales service only.

The contents are subject to change without notice.

SPECIFICATIONS

Models	AF-P80CX	
Cooling capacity	BTU/h	8000
Moisture removal	Pints/h	2.3
ELECTRICAL DATA		
Phase	Single	
Rated frequency	Hz	60
Rated voltage	Volts	115
Rated current	Amps	6.7
Rated input	Watts	730
Power factor	%	95
EER	BTU/Wh	11.0

COMPRESSOR

Type	(Hermetically sealed rotary type)	
Model, Motor output	2R12T126A-6A, 550W	

REFRIGERANT SYSTEM

Evaporator	Louver fin, Grooved tube, 7mm, Hair pin	
Condenser	Louver fin, Grooved tube, 7mm, Hair pin	
Control O.D. x I.D. x Length x Q'ty(mm) (Capillary tube)	2.7 x 1.0 x 800 x 2	
Refrigerant volume R-22(OZ) (Factory change)	15.5	

NET DIMENSIONS

Width Height Depth	inches(mm)	19-11/16(500) x 14-9/16(370) x 17-3/32(434)
Net Weight	lbs	53

GROSS DIMENSIONS

Width Height Depth	inches(mm)	22-27/32(580) x 18-5/16(465) x 19-31/32(507)
Gross Weight	lbs	60

FAN SYSTEM


Indoor side(Evaporator)	Centrifugal fan	
Outdoor side(Condenser)	Propeller fan	
Air flow rate(indoor side)	CFM	High / Med / Low
		187 / 173 / 155

OTHERS

Safety devices	Compressor: Overload relay Fan motor: Internal thermal protector	
Air filter	Polypropylene net	
Power cord length	ft	6.0
Power plug type	125V, 10A	

ELECTRICAL PARTS

Models	AF-P80CX
Running capacitor	250V-35 μ F
Fan capacitor	250V-6 μ F
Thermistor	15k Ω at 78°F
Fan motor	OBM-2508K1 (MLB003)
Overload relay	MRA98706

WIRING DIAGRAM**Figure W-1**

EXTERNAL DIMENSIONS





Fig. E-1

HOW TO OPERATE


PARTS NAMES

UNIT




- ① Front Cabinet
- ② Air Inlet (Indoor Side)
- ③ Horizontal Louvers
- ④ Vertical Louvers
- ⑤ Air Outlet (Indoor Side)
- ⑥ Control Panel
- ⑦ Rear Cabinet
- ⑧ Air Inlet (Outdoor side)
- ⑨ Filter (Pull the filter handle to the right to remove.)
- ⑩ Filter Handle
- ⑪ Power Cord

CONTROL PANEL



- ① Receiver window for remote control signal
- ② Display
- ③ SELECTOR indicator
- ④ SELECTOR pad
- ⑤ TEMPERATURE setting pad
 - ∨ ----Lower temp. ^ ----Raise temp.
- ⑥ TIMER ON/OFF pad
- ⑦ TIMER indicator
- ⑧ ENERGY SAVER pad
- ⑨ ENERGY SAVER indicator
- ⑩ POWER ON/OFF pad
- ⑪ POWER indicator
- ⑫ PLASMACLUSTER indicator

COOLING OPERATION




1 Touch POWER ON/OFF pad.

- The unit is preset at 74°F and HIGH COOL. This will show in the display when the power is first turned on.
- POWER indicator and SELECTOR indicator (COOL) will light.

2 To turn off the unit, touch POWER ON/OFF pad again.

- POWER indicator and SELECTOR indicator will go off.

TO CHANGE TEMPERATURE SETTING



During cooling operation

Touch the **TEMPERATURE** setting pad to adjust the temperature setting.

- ∨ ---Lower temp.
- ∧ ---Raise temp.

- Temperature can be set within the range of 64°F to 86°F.
- Display will change as you touch the pad.

NOTE:


- The latest temperature setting will be memorized and will appear on the display the next time the unit is turned on.
- In cases of power outages or when the unit is disconnected; when the power is restored or the unit is plugged in, the unit and display will return to the preset conditions of 74°F and HIGH COOL. The unit will not automatically turn back on. The user must touch POWER ON/OFF to resume operation.



- The latest operation mode will be memorized and the selector indicator and display will light when the unit is turned on.
- In fan only operation, the temperature display will go off.
- When the SELECTOR is changed to fan only operation from cooling operation, it will take 5 seconds for the compressor to stop.

ENERGY SAVER

During normal operation, the thermostat automatically controls cooling and the fan runs continuously. When the ENERGY SAVER is selected, the thermostat automatically controls cooling and the fan automatically stops when the compressor is not operating. (Fan will stop 30 seconds after the compressor stops. After the fan stops, the fan is programmed to rotate for approx. 2 minutes to detect room temperature. This will occur within a 20 min time span.)





During cooling operation

- 1 Touch ENERGY SAVER pad.**
 - ENERGY SAVER indicator will light.
- 2 To cancel, touch ENERGY SAVER pad again.**
 - ENERGY SAVER indicator will go off.

NOTE: ENERGY SAVER cannot be set during fan only (HIGH FAN, MED FAN, LOW FAN) operation.

TO CHANGE AIR FLOW DIRECTION


The horizontal louvers are used to adjust the UP / DOWN direction of air flow, and the vertical louvers are used to adjust the LEFT / RIGHT direction of air flow for uniform and efficient cooling of the room.



ON TIMER OPERATION

- This unit has a built-in timer that can be programmed to start the unit up to 12 hours in advance. You can set the timer to start in increments of 30 minutes (0.5 hours) up to 9.5 hours in advance of the start time, or in 1 hour increments from 10 to 12 hours in advance of the start time.
- The unit will start automatically according to your setting.

SELECTOR indicator



TIMER ON/OFF pad


TIMER indicator

(If you wish to start the operation 6 hours and 30 minutes later, set the delay time as shown above.)

When the unit is not operating

1 Touch the TIMER ON/OFF pad to set the delayed start time.

- The time setting will change as you touch the pad. The display will change as follows;



- The timer will be set, 5 seconds after the TIMER ON/OFF pad is touched for the last time.
- SELECTOR indicator and TIMER indicator will light.
- The time display will count down the remaining time.
- The unit will start when the set time expires. The temperature setting will be displayed.

TO CANCEL THE TIMER SETTING


Touch the TIMER ON/OFF pad again after the timer is set, or press the TIMER ON/OFF pad until CL(cancel) appears on the display.

NOTES FOR TIMER SETTING AND OPERATION:

- After setting the TIMER, change the temperature and fan speed settings as shown on pages 11 and 12. When the temperature is set in the timer mode, the temperature will show in the display for 5 seconds and then return to the time display.
- The last setting used will be memorized and will appear on the display the next time you operate the unit with the TIMER function.
- If a power failure occurs while the ON or OFF TIMER is set, the TIMER memory will be cancelled and will not resume even after power is reinstated. The unit will not automatically start.
- OFF TIMER OPERATION can also be set with the REMOTE CONTROL.

OFF TIMER OPERATION

- This unit has a built-in timer that can be programmed to shut the unit off up to 12 hours in advance. You can set the timer to stop in increments of 30 minutes (0.5 hours) up to 9.5 hours in advance of the stop time, or in 1 hour increments from 10 to 12 hours in advance of the stop time.
- The unit will stop automatically according to your setting.



TIMER ON/OFF pad


TIMER indicator

(If you wish to stop the operation 10 hours later, set the delay time as shown above.)

When the unit is operating

1 Touch the TIMER ON/OFF pad to set the delayed stop time.

- The time setting will change as you touch the pad. The display will change as follows;



- The timer will be set, 5 seconds after the TIMER ON/OFF pad is touched for the last time.
- TIMER indicator will light.
- The time display will count down the remaining time.
- The unit will stop when the set time expires. All indicators and displays will go out.

TO CANCEL THE TIMER SETTING


Touch the TIMER ON/OFF pad again after the timer is set or, press the TIMER ON/OFF pad until CL(cancel) appears on the display.

USING THE REMOTE CONTROL

INSTALLING BATTERIES

Use two AA (R6) batteries.

- 1** Remove the battery compartment cover.
- 2** Insert the batteries in the compartment, making sure the \oplus and \ominus polarities are properly aligned.
- 3** Replace the cover.



NOTES:

- The battery life is approximately one year with normal use.
- When you replace the batteries, always use two new ones of the same type.
- If the remote control does not operate normally after replacing the batteries, take out the batteries and replace them again after 30 seconds.
- If you will not be using the unit for a long time, remove the batteries from the remote control.


HOW TO USE THE REMOTE CONTROL

Point the remote control towards the unit's receiver window and press the desired button. A beep will sound when the unit receives the signal.


- Make sure no objects, such as curtains, block the receiver window.
- The remote control operates from up to 20 feet (6 meters) away.
- The beep will also sound when each pad on the control panel is touched.

CAUTION:


- Do not expose the receiver window to direct sunlight. This can adversely affect its operation. In such case, close the curtains to block the sunlight.
- Use of a fluorescent lamp in the same room may interfere with the transmission of the signal.
- The unit may be affected by signals emitted from the remote control of a television, VCR or other equipment used in the same room.
- Do not leave the remote control exposed to direct sunlight or near a heater. Protect the remote control from moisture and shock which can discolor or damage it.



OPERATING WITH THE REMOTE CONTROL



- The time setting will change as you push the button. The display will change as follows;



- The last OFF time setting is memorized by the unit and will appear on the display when the button is pushed.
- The timer will be set, 5 seconds after the SET TIMER/OFF button is pushed for the last time.
- If you wish to cancel the timer, push the SET TIMER/OFF button again after the time is set or, push the SET TIMER/OFF button until CL (cancel) appears on the display. A double beep will sound when the timer is cancelled.
- The "ON" TIMER cannot be set with the remote control. It can only be activated by the TIMER ON/OFF pad on the unit's control panel (See page 9).


To change temperature setting when ON/OFF timer is in use

- Push a TEMPERATURE setting button.
 The current set temperature will be recalled on the unit's display.
- Use the TEMPERATURE setting buttons to set the new temperature.
 The new set temperature will show on the display for 5 seconds and return to the time display.

PLASMACLUSTER OPERATION

Cluster ions are released into the room, keeping air your room clean.


PLASMACLUSTER button



During operation

- 1 Press PLASMACLUSTER button.**
 - PLASMACLUSTER indicator will light.

PLASMACLUSTER indicator



- 2 To cancel, press PLASMACLUSTER button again.**
 - PLASMACLUSTER indicator will go off.


NOTE:

PLASMACLUSTER operation will be memorized when once set and will start its operation the next time the unit is turned on.

NOTE FOR PLASMACLUSTER OPERATION

The ionizer inside the air conditioner will discharge cluster ions, which are collective mass of positive and negative ions, into the room.


The cluster ions reduce airborne mold fungus and deodorize/decompose odor-causing molecules.



INSTALLATION INSTRUCTIONS

ACCESSORIES

No.	Accessories	Q'ty
①	Right closure assembly	1
②	Left closure assembly	1
③	Window sash foam seal	1
④	Window sash foam seal (adhesive type)	1
⑤	Bottom gasket	1
⑥	Screws (L=1", 25.4mm)	7
⑦	Screws (L= $\frac{13}{32}$ ", 10mm)	6
⑧	Base pan angle	2
⑨	Remote control	1
⑩	Battery	2




SUGGESTED TOOLS

1. Screw driver (medium size Phillips)
2. Tape measure or ruler
3. Knife or scissors


INSTALLATION

WARNING: Make sure the unit is turned off and unplugged before working.

- 1 Cut the window sash foam seal (adhesive type) to the proper length and attach it to the underside of the window sash.




- 2 Insert the right closure assembly and the left closure assembly into the top angle and the bottom channels. Secure the right and left closure to the cabinet with six of the provided screws. (L= $1\frac{3}{32}$ " , 10mm)




- 3 Open the window sash and place the air conditioner on the sill.

Balance the unit on the sill and close the window sash securely behind the top angle.




WARNING:

At this step, make sure the unit is inclined approximately 1 cm ($\frac{3}{8}$ ") to the back. If the unit is not properly inclined, the water collected in the bottom tray during operation will not drain properly and may flow into the room where the air conditioner is installed.




- 4 Insert the bottom gasket into the space between the window sill and the bottom of the unit to seal outside air.


If there is space between the bottom channel and the sill, fill the gap with a thin board or other hard filler.




- 5** Insert the closure assemblies on both sides into the rails of the jamb.




- 6** Loosen screws on both sides of the cabinet, then hang the base pan angle on and secure the screws again.




- 7** Secure the base pan angle to the sill by using the hole of the front side on the angle with one screw. (L=1", 25.4mm)



- 8** Secure the top angle of the unit and the top of the closure assemblies to the sash with three of the provided screws. (L=1", 25.4mm)
And secure the bottom of the closure assemblies to the sill with two of the provided screws. (L=1", 25.4mm)



- 9** Cut the window sash foam seal to the proper length and seal the opening between the top of the inside window sash and the outside window sash.




Window sash foam seal


DISASSEMBLING PROCEDURE

CAUTION: DISCONNECT THE ROOM AIR CONDITIONER FROM THE POWER SUPPLY BEFORE ANY SERVICE


1. Unscrew the 2 screws holding the front panel on each side.




5. Unscrew the 2 screws holding wire fixing band.




2. Remove the front panel by pulling the front panel at the lower corner toward you about one inch. Next lift up and pull it toward you.




6. Unscrew the 2 screws holding cover and holder.




3. Unscrew the 8 screws holding the cabinet.
2 screws are on each side.
4 screws are on back side.
2 screws are on top side.
And remove the cabinet.




7. Remove the control panel.




8. Take off the fan motor connector.




4. Remove the thermistor holder.




9. Unscrew the 5 screws.
3 screws are holding the control box at the top and right side.
1 screw is holding the power supply cord.
1 screw each screw on the evaporator.




10. Cut the wire fixing band, slide the control box rightward and remove.




11. Unfasten the one nut at the top of the compressor holding the terminal cover. Then remove the wiring connector of the compressor cord.




12. Unscrew the 4 screws holding the condenser.
1 screw is on right side.
1 screw is on left side.
2 screws are on back side.
And remove the condenser from the unit.




13. Unfasten the nut holding the propeller fan by rotating it counter-clockwise. And remove the propeller fan.




14. Unscrew the 2 screws holding the condenser shroud. And remove the condenser shroud.




15. Unscrew the 7 screws.
4 screws are holding the evaporator on each side.
3 screws are holding the bulkhead to the base pan on each side and back side.




16. Lift up and take out the bulkhead.




17. Unscrew the 1 screw holding the orifice.




18. Unscrew the 1 screw holding the top duct ass'y.



19. Unscrew the 1 screw holding the centrifugal fan.




20. Unscrew the 1 screw holding wire holder.
Unscrew the 3 screws holding fan motor.




DISASSEMBLING THE CONTROL BOX


1. Unscrew the 1 screw holding the control box cover.
CAUTION: DISCHARGE THE FAN MOTOR CAPACITOR AND RUNNING CAPACITOR BEFORE TOUCHING THOSE CAPACITORS OR OTHER COMPONENTS OR WIRING.




4. Unscrew the 1 power supply cord grounding screw.
Unscrew the earth screw. Unscrew the 1 screw holding the capacitor clamp and the fan motor capacitor.




2. Unscrew the 3 screws holding the printed wiring board.




5. Detach each connector by using long-noise pliers.



3. Cut the wire fixing bands holding the fan motor lead wires, the compressor cord and the power supply cord.



6. Unscrews the 2 screws holding the transformer and remove the control board with unhooking the 2 spacers.



HOW TO REPAIR REFRIGERATION

Before sealed system work can be performed a refrigerant recovery EPA and LOCALLY approved certification is required, additionally, EPA and LOCALLY approved refrigerant recovery equipment is required.

SEALED SYSTEM REPAIR

Sealed system repairs should be properly diagnosed before entering into a repair of the system.

It is important to follow proper procedures when doing a system repair for safety reasons and that the repair will result in a restoration of the system to proper factory standards.

SAFETY REMINDERS

- 1) Do not heat any system component with an open flame for any reason.
- 2) Do not solder until you are sure that all refrigerant has been removed from the system.
- 3) Do not heat the charging cylinder with an open flame. Use warm water only and do not exceed 125°F (not too hot to keep your hand in.)
- 4) Do not over fill any charging cylinders, as they could explode when over filled.
- 5) Use proper wrenches.
- 6) Use safety goggles when working with refrigerants.
- 7) Keep a fire extinguisher within easy reach.
- 8) Watch flame direction when soldering so as not to burn clothing, wiring or other components.
- 9) Solder in a well ventilated area. If a high concentration of freon is present, an open flame will create phosgene gas which can be harmful.

PROPER SOLDERING

Joint clearances should be maintained so that the brazing alloy will flow between the closely mated surfaces rather than forming large fillets.

This films make the strongest joints, capillary attraction also work best with close tolerance.

The best clearance is between 0.01" to 0.03" , the amount of lap will be approximately 3/8" depending on the swaging tool used. (Figure 1.)





Figure 1

CLEANING TUBING

To make a sound, leak tight joint, the brazing alloy when raised to brazing temperature, must wet and flow freely over the entire surface of the tubing in the joint area.

To assure this, the tubing surfaces must be free of all dirt, grease, oil and oxides otherwise the alloy will not wet and flow properly over any surface with these elements present. Cleaning can be done with an abrasive cloth or steel wool. Never blow into the tubing because this will introduce a lot of moisture into the system. Open tubing joints should be covered if exposed for long periods of time.



Cleaning Tubing.

Figure 2


PROPER FLUXING

Flux is necessary when using silver solder; it is not required when using silfos on copper to copper joints.

To do a good job the flux should cover the tube surface completely. Be careful not to introduce any flux inside the tubing.

Fluxing should be done after the tubing is mated together and just before brazing is done. Do not allow it to dry out.

When brazing, the flux should become entirely liquid and clear, like water. The temperature will be at 1100°F and only a little more heat will allow the alloy to flow freely into the joint.



Directing Torch Flame to Copper Tubing.


Figure 3

HEATING THE TUBING

Direct the torch flame so that the larger tube receives most of the heat. Silver solder flows at 1200°F and silfos flows at 1300°F.

Heat all around the tubing.

The flame is composed of two cones, a smaller inner cone (pale blue) in color and a much larger outer cone. The hottest part of the flame is at the tip of the inner cone. The flame should be directed at the joint with the tip of the cone just touching the surface of the tubing. Figure 3 and 4.



Composition of Torch Flame.

Figure 4

DEHYDRATING SEALED SYSTEM

Many servicers feel that since air conditioners run with evaporator temperatures above 33°F, moisture will not present a problem. Nothing is further from the truth. Oxygen in moisture plus the heat produced during compression will react with the refrigerant oil to produce harmful acids in the system which will break down motor winding insulation, create sludge and pit component parts, reducing efficiency of the air conditioner and shortening the life of compressors.

There it becomes mandatory that good dehydrating practices be adhered to at all times.

Proper hook up procedures as shown in Figure 5 must be used in order to pull a good vacuum from the system.

The use of a good vacuum pump is very important so that the boiling point of any water in the system will be lowered to a point where it will vaporize and be expelled from the system in the form of vapour.

Type of evacuation methods

1. **Piston Type Compressor** No good.
System parts must be above 110°F.
2. **Rotary Vacuum Pump** Disadvantages.
Low CFMC. 4 oil gets dirty.
3. **Single State Vacuum Pump** will not clean oil.
Oil must be changed often.
4. **Two Stage Vacuum Pump** will reach 50 microns.
First stage is below atmospheric pressure.
Moisture is removed into second stage which works up to atmospheric pressure thus keeping oil clean.
Manometer cannot be read to 1/2 mm. Micron gauge reads from 25,400 microns to 0.




Figure 5

It becomes clear that good equipment and maintained properly must be used in order to remove air and moisture from the system.

When a vacuum of 1,000 to 500 microns is reached, block off the vacuum pump from the system.

This is done by closing the valve between the pump and system. If the micron gauge does not increase above 1,000, the system is free of moisture and no leak exists. If the micron gauge increases to higher levels moisture or a leak exists.

LEAKS

Several methods are used to detect leaks in systems.

Electronic Leak Detectors are very sensitive and are able to detect leaks down to 1/2 ounce per year.

A good electronic leak detector is generally far better in locating very small leaks.

Halide Torch be sure the room is free from refrigerant vapours. Watch the flame for the slightest change in color.

A very faint green indicates a small leak. The flame will be unmistakably changed to green or purple when large leaks are encountered. To simplify leak detection pressurize the system to approximately 75 lbs.

Some leaks can be located by a visual inspection of the system components and solder joints and if oil is found at any given location it generally is a sign that a leak exists at that point due to the fact that flame does carry oil with it travels through the system.

Soap Bubbles

Liquid detergents can sometimes assist in finding small leaks by brushing detergent on the suspect area and watching for bubbles. Before applying detergent be sure that the system is pressurized.


Tap line devices are permissible for diagnosis only they are not suitable when evacuating the system. After the diagnosis has been made they must be removed so that the system will be restored to a hermetically sealed condition.

ELECTRICAL COMPONENT TEST

RUNNING CAPACITOR AND FAN CAPACITOR

CAUTION: DISCHARGE THE RUNNING CAPACITOR AND FAN CAPACITOR BEFORE TOUCHING CAPACITOR OR WIRING.

- (1) Discharge capacitor by shorting terminals.
- (2) Take the wires off the capacitor terminals.
- (3) Set the selector switch of a volt-ohm-meter (or a tester) on the resistance range.
- (4) Connect the probes to the capacitor terminals and watch the indicator swing.
The indicator does not swing at all Open.
The indicator swings but does not return Shorted.
The indicator swings, then returns a moment later Good.



INSULATION TEST

Check the resistance between the terminals and case.
Reading must be more than $10M\Omega$ at DC 500V.

OVERLOAD RELAY

Check continuity between terminals with volt-ohm-meter.

INSULATION TEST

Check resistance between terminals and the relay case.
Reading must be more than $10M\Omega$ at DC 500V.

COMPRESSOR

- (1) Take the wires off compressor terminals.
- (2) Set selector switch of volt-ohm-meter on the resistance range.
- (3) Put the probes on the terminals of the compressor and check continuity between each terminal.

INSULATION TEST

Check the resistance between the terminals and the copper tube.
Reading must be more than $10M\Omega$ at DC 500V.

MICROCOMPUTER CONTROL SYSTEM

1. Temperature control characteristic

1-1 COOL operation

In the "COOL" mode, the thermostat circuit is controlled by two thermostat lines (C1, C2).




Figure Y-1

2. Operation mode

2-1 COOL operation

The compressor turns on or off, at thermostat lines C1 and C2. The fan motor is also controlled with the compressor.




Figure Y-2

2-2 FAN ONLY operation

The fan motor always turns on.

3. Fan speed

Fan speeds are given by the fan motor, "H", "M" and "L", which are available in the following operation mode.

Table Y-1

Selector	Fan motor
HIGH COOL	H
MED COOL	M
LOW COOL	L
HIGH FAN	H
MED FAN	M
LOW FAN	L

4. 12-hours timer

4-1 OFF-TIMER operation

Set the delay timer during operation.

The unit will turn off automatically according to your setting. Timer duration can be set by 0.5 hours to maximum 12 hours. Up to 9.5 hours, you can set by 0.5 hours increments and from 10 to 12 hours, by 1 hour increment.

If you touch button "POWER ON/OFF" during OFF-TIMER operation, then the unit turns off and OFF-TIMER operation is cancelled.

4-2 ON-TIMER operation

Set the delay timer when unit is not operating.

The unit will turn on automatically according to your setting. Timer duration can be set by 0.5 hours to maximum 12 hours. Up to 9.5 hours, you can set by 0.5 hours increments and from 10 to 12 hours, by 1 hour increment.

If you touch button "POWER ON/OFF" during ON-TIMER operation, then the unit turns on and ON-TIMER operation is cancelled.

ON-TIME and OFF-TIME display will count down the remaining time.

from 0.5 to 9.5 0.5 hours
from 10 to 12 1 hour

5. Energy saver

During normal operation, the thermostat automatically controls cooling and the fan runs continuously whenever the air conditioner is in operation.

When the ENERGY SAVER is set, the thermostat automatically controls cooling and the fan automatically stop when compressor is not operating. (Fan will stop in 30 seconds after the compressor stops.)




Figure Y-3

6. Plasmacluster

During operation when Plasmacluster button is pushed, Plasmacluster indicator will light, and Cluster ions from High Voltage Unit are released into the room.

6. Safety start

When you turn the air conditioner OFF and restart again soon, wait at least 3 minutes before the cooling operation starts.

7. Test mode

Keep pushing both buttons "POWER ON/OFF" and "▼" and supply the power, the system will go to the test mode. In this mode, the output operation is switched by pushing buttons. Normal outputs are shown in Table Y-2.

Table Y-2

For selfdiagnosis check mode

No.	PUSH KEY (SWITCH)	BEPP SOUND	LED1	LED LIGHTING									OUTPUT CHECK			CHECK ITEM and REMARK
				FAN HIGH <LED2>	FAN MID <LED3>	FAN LOW <LED4>	COOL <LED9>	FAN <LED5>	TIMER <LED7>	ENERGY SAVER <LED8>	POWER ON/OFF <LED6>	CLUSTER <LED10>	FAN OUTPUT	COMP OUTPUT	CLUSTER OUTPUT	
0	PLUG IN the power supply cord while pushing power ON/OFF key and ▼ (down) key.	2	8.8	ON	ON	ON	ON	ON	ON	ON	ON	ON	OFF	OFF	OFF	LED ALL ON
1	SELECTOR <SW3>	1	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	LOW	OFF	ON	LED ALL OFF
2	▽ <SW6>	1	01	OFF ※ 2)	OFF ※ 3)	OFF ※ 4)	OFF	OFF	OFF	OFF	※ 1)	OFF	MIDDLE	OFF	ON	
3	△ <SW5>	1	02	ON	OFF	OFF	ON	OFF	OFF	ON	OFF	OFF	HIGH	OFF	ON	
4	TIMER <SW2>	1	03	OFF	ON	OFF	OFF	ON	OFF	OFF	ON	ON	OFF	OFF	OFF	FAN CHECK
5	ENERGY SAVER <SW1>	1	04	OFF	OFF	ON	OFF	OFF	ON	OFF	OFF	OFF	LOW	OFF	OFF	
6	ON/OFF <SW4>	1	05	ON	OFF	OFF	ON	OFF	OFF	ON	OFF	OFF	HIGH	ON	OFF	
7	POWER ON/OFF by REMOTE CONTROL	1	05	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	MIDDLE	OFF	OFF	COMPRESSOR CHECK
8	POWER SUPPLY OFF	—	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	REMOTE CONTROL CHECK

※ 1) If thermistor is normal (nether short nor open), LED is ON.

※ 2) When A/D (R42) bit 7 = 1, LED is ON.

※ 2) When A/D (R42) bit 6 = 1, LED is ON.


※ 2) When A/D (R42) bit 5 = 1, LED is ON.

Table Y-3

T(°C)	T(°F)	R(kΩ)	※ V(volts)
0	32.0	49.33	1.17
1	33.8	46.86	1.21
2	35.6	44.53	1.26
3	37.4	42.33	1.31
4	39.2	40.25	1.36
5	41.0	38.29	1.41
6	42.8	36.44	1.46
7	44.6	34.68	1.51
8	46.4	33.02	1.56
9	48.2	31.45	1.61
10	50.0	29.96	1.67
11	51.8	28.55	1.72
12	53.6	27.22	1.78
13	55.4	25.96	1.83
14	57.2	24.76	1.89
15	59.0	23.62	1.94
16	60.8	22.56	2.00
17	62.8	21.52	2.05
18	64.4	20.55	2.11
19	66.2	19.63	2.17
20	68.0	18.76	2.22


T(°C)	T(°F)	R(kΩ)	※ V(volts)
21	69.8	17.93	2.28
22	71.6	17.14	2.33
23	73.4	16.39	2.39
24	75.2	15.68	2.44
25	77.0	15.00	2.50
26	78.8	14.36	2.55
27	80.6	13.74	2.61
28	82.4	13.16	2.66
29	84.2	12.60	2.71
30	86.0	12.07	2.77
31	87.8	11.57	2.82
32	89.6	11.09	2.87
33	91.4	10.63	2.93
34	93.2	10.19	2.98
35	95.0	9.78	3.03
36	96.8	9.38	3.08
37	98.6	9.00	3.13
38	100.4	8.64	3.17
39	102.2	8.30	3.22
40	104.0	7.97	3.27

※ V Input the voltage of microcomputer (No. 10-port).




Electronic Control Circuit Diagram


— IF NOT SPECIFIED 1/5W, ±5% (RESISTOR)
 — IF NOT SPECIFIED 50V 1000pF (CAPACITOR)
 — IF NOT SPECIFIED 1SS133T-72 (DIODE)
 Δ : INDICATED POSITION IS FUNCTION TEST POINT





Printed Wiring Board


TROUBLESHOOTING GUIDE









※ Checking method for the compressor relay.
(MRY and PWB)








COOLING LOAD ESTIMATE FORM

INSTRUCTIONS FOR USING COOLING LOAD ESTIMATE FORM FOR ROOM AIR CONDITIONERS

(AHAM PUB. NO. RAC-1)

- A. This cooling load estimate form is suitable for estimating the cooling load for comfort air conditioning installations which do not require specific conditions of inside temperature and humidity.
- B. The form is based on an outside design temperature of 95°F dry bulb and 75°F wet bulb. It can be used for areas in the continental United States having other outside design temperature by applying a correction factor for the particular locality as determined from the map.
- C. The form includes "day" factors for calculating cooling loads in rooms where daytime comfort (such as living rooms, offices, etc.).
- D. The numbers of the following paragraphs refer to the correspondingly numbered item on the form:
 1. Multiply the square feet of window area for each exposure by the applicable factor. The window area is the area of the wall opening in which the window is installed. For windows shaded by inside shades or venetian blinds, use the factor for "Inside Shades". For windows shaded by outside awnings or by both outside awnings and inside shades (or venetian blinds), use the factor for "Outside Awnings". "Single Glass" includes all types of single thickness windows, and "Double Glass" includes sealed air space types, storm windows, and glass block. Only one number should be entered in the right-hand column for item 1, and this number should represent only the exposure with the largest load.
 2. Multiply the total square feet of all windows in the room by the applicable factor.
 - 3a. Multiply the total length (linear feet) of all walls exposed to the outside by the applicable factor. Doors should be considered as being part of the wall. Outside walls facing due north should be calculated separately from outside walls facing other directions. Walls which are permanently shaded by adjacent structures should be considered as being "North Exposure". Do not consider trees and shrubbery as providing permanent shading. An insulated frame wall or a masonry wall 8 inches or less in thickness is considered "Light Construction". An insulated frame wall or a masonry wall over 8 inches in thickness is considered "Heavy Construction".
 - 3b. Multiply the total length (linear feet) of all inside walls between the space to be conditioned and any unconditioned spaces by the given factor. Do not include inside walls which separate other air conditioned rooms.
 4. Multiply the total square feet of roof or ceiling area by the factor given for the type of construction most nearly describing the particular application. (Use one line only.)
 5. Multiply the total square feet of floor area by the factor given. Disregard this item if the floor is directly on the ground or over a basement.
 6. Multiply the number of people who normally occupy the space to be air conditioned by the factor given. Use a minimum of 2 people.
 7. Determine the total number of watts for lights and electrical equipment, except the air conditioner itself, that will be in use when the room air conditioning is operating. Multiply the total wattage by the factor given.
 8. Multiply the total width (linear feet) of any doors or arches which are continually open to an unconditioned space by the applicable factor.
NOTE: Where the width of the doors or arches is more than 5 feet, the actual load may exceed the calculated value. In such cases, both adjoining rooms should be considered as a single large room, and the room air conditioner unit or units should be selected according to a calculation made on this new basis.
 9. Total the loads estimated for the foregoing 8 items.
 10. Multiply the sub total obtained in item 9 by the proper correction factor, selected from the map, for the particular locality. The result is the total estimated design cooling load in BTU per hour.
- E. For best results a room air conditioner unit or units having a cooling capacity rating (determined in accordance with the NEMA Standards Publication for Room Air Conditioners, CN 1-1960) as close as possible to the estimated load should be selected. In general, a greatly oversized unit which would operate intermittently will be much less satisfactory than one which is slightly undersized and which would operate more nearly continuously.
- F. Intermittent loads such as kitchen and laundry equipment are not included in this form.

HEAT GAIN FROM	QUANTITY	FACTORS			BTU/Hr (Quantity x Factor)
		DAY			
		No Shades	Inside Shades	Outside Shades	(Area a Factor)
1. WINDOWS: Heat gain from sun.					
Northeast	_____ sq ft	60	25	20	Use _____
Southeast	_____ sq ft	80	40	25	only _____
South	_____ sq ft	75	30	20	the _____
Southwest	_____ sq ft	75	35	20	largest _____
Southeast	_____ sq ft	110	45	30	load _____
West	_____ sq ft	150	65	45	Use _____
Northwest	_____ sq ft	120	50	35	only _____
North	_____ sq ft	0	0	0	only _____
These factors are for single glass only. For glass block, multiply the above factors by 0.5; for double-glass or storm windows, multiply the above factors by 0.8.					
2. WINDOWS: Heat gain by conduction. (Total of all windows)					
Single glass	_____ sq ft	14			_____
Double glass or glass block	_____ sq ft	7			_____
3. WALLS: (Based on linear feet of wall.)					
a. Outside walls		Light Construction		Heavy Construction	
Noth exposure	_____ ft	30		20	
Other than North exposure	_____ ft	60		30	
b. Inside Walls (between conditioned and unconditioned spaces only)	_____ ft			30	
4. ROOF OR CEILING: (Use one only.)					
a. Roof, uninsulated	_____ sq ft	19			_____
b. Roof, 1 inch or more insulation	_____ sq ft	8			_____
c. Ceiling, occupied space above.	_____ sq ft	3			_____
d. Ceiling, insulated with attic space above	_____ sq ft	5			_____
e. Ceiling, uninsulated, with attic space above	_____ sq ft	12			_____
5. FLOOR: (Disregard if floor is directly on ground or over basement.) _____ sq ft					
6. NUMBER OF PEOPLE: 600					
7. LIGHTS AND ELECTRICAL EQUIPMENT IN USE _____ watts					
8. DOORS AND ARCHES CONTINUOUSLY OPENED TO UNCONDITIONED SPACE: (Linear feet of width.) _____ ft					
9. SUB-TOTAL x x x x x x x x x x x					
10. TOTAL COOLING LOAD: (BTU per hour to be used for selection of room air conditioner(s).) _____ (Item 9) x _____ (Factor from Map) = _____					




RUNNING CONDITION

Note:


1. Select mode of the Running Condition of a Room Air Conditioner.
 SELECTOR HIGH COOL
 THERMOSTAT 64°F
2. Data of Performance Curve is measured between 40%RH and 70%RH.
 If you measure the Room Air Conditioner above or below this rating, the data may miss the range of the performance curve.
3. Outlet air temp. is influenced by the method of measurement. Measurement examples are shown.
4. Use power input data when checking the Running Condition.

RUNNING CONDITION FOR

PERFORMANCE CURVE



PACKING AND ACCESSORIES



REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	Q'TY	CODE
CABINET AND UNIT PARTS				
1- 1	CMOTLB003JBEZ	Fan motor	1	BM
1- 2	DCHS-A364JBTA	Base pan ass'y	1	BC
1- 3	PFPFPB137JBE0	Base pan insulator	1	AF
1- 4	PFPFPB138JBE0	Base pan insulator	1	AF
1- 5	CCAB-A318JBKZ	Cabinet ass'y	1	BB
1- 6	CWAK-C205JBKZ	Top duct ass'y	1	AS
1- 7	HPNLCA805JBFA	Control panel	1	AE
1- 8	HPNLCA827JBEA	Control panel	1	AF
1- 9	PSEL-B825JBE0	Insulator	1	AE
1-10	LBND-A042JBE0	Wire fixing band	3	AC
1-11	LHLDW0364JBE0	Wire holder	1	AA
1-12	PSHE-A172JBE0	Protect sheet	1	AC
1-13	NFANPA078JBF0	Propeller fan	1	AU
1-14	NFANSA027JBF0	Centrifugal fan	1	AU
1-15	PFILMA164JBEA	Air filter	1	AK
1-16	PKESPA034JBF0	Condenser shroud	1	AV
1-17	PKESSA057JBF0	Orifice	1	AK
1-18	PSEL-A827JBE0	Evaporator insulator	1	AB
1-19	PSEL-A994JBE0	Orifice insulator	1	AB
1-20	PSEL-A828JBE0	Motor insulator	1	AB
1-21	TLABMA332JBRZ	Feature card	1	AG
1-22	PSEL-C085JBEZ	Tube insulator	1	AC
1-23	PSKR-A245JBFZ	Bulkhead	1	BC
1-24	PSRA-A078JBF0	Drain tray	1	AD
1-25	MJNTPA090JBFA	Louver link	1	AC
1-26	MLOV-A333JBFA	Horizontal louver	4	AC
1-27	MJNTPA089JBFA	Louver joint	1	AC
1-28	MLOV-A321JBFA	Vertical louver A	1	AC
1-29	MLOV-A322JBFA	Vertical louver B	3	AC
1-30	MSPR-A148JBEZ	Louver spring	2	AF
1-31	LANG-A213JBTA	Top inst.angle	1	AF
1-32	LPLTMA087JBP0	Condenser cover	1	AB
1-33	GWAKPA151JBFA	Front panel	1	AV
1-34	PSEL-B845JBE0	Insulator	1	AB
1-35	TLABBA110JBRA	Sharp badge	1	AB
1-36	TLABKA564JBE0	Number card	1	AC
1-37	TLAB-C272JBEZ	Energy card	1	AC
1-38	TSPC-E141JBRZ	Name badge	1	AC
1-39	LHLD-A315JBF0	Thermistor holder	1	AE
1-40	PFPFPB745JBE0	Comp-cushion	1	AE
1-41	DSKR-A125JBKZ	Bulkhead ass'y	1	BG
1-42	TLAB-B482JBR0	Energy start label	1	AA
1-43	HDEC-B152JBEA	Display panel	1	AG
1-44	LHLDW0366JBE0	Wire holder	1	AA
1-45	LBND-A091JBEZ	Wire fixing band	2	AF
1-46	PCOV-A786JBFA	Cover	1	AG
1-47	CKITTA007JBKZ	High voltage unit ass'y	1	BH
1-48	PFPFPB181JBEZ	Holder insulator	1	AE
1-49	LHLD-A583JBFA	Holder	1	AM
1-50	DHLD-A012JBKZ	Holder ass'y	1	AE

CONTROL BOX PARTS

2- 1	DPLT-A056JBWZ	Cont. box angle ass'y	1	AK
2- 2	LBNDKA058JBWZ	Capacitor clamp	1	AD
2- 3	DPLT-A038JBW0	Cont. box cover ass'y	1	AK
2- 4	DPWBFA277JBKZ	Control board unit	1	BS
2- 5	PSPA-A084JBE0	Spacer	2	AC
2- 6	PSPA-A085JBE0	Spacer	1	AC
2- 7	QACC-A260JBZZ	Power supply cord	1	AS
2- 8	QFS-AA048JBE0	Fuse	1	AB
2- 9	TLABCB618JBRZ	Wiring diagram	1	AB
2-10	QW-VZC561JBE0	Lead wire	1	AD
2-11	QW-VZD376JBE0	Compressor cord	1	AR
2-12	RC-HZA256JBE0	Fan motor capacitor	1	AM
2-13	RC-HZA136JBE0	Running capacitor	1	AU
2-14	RH-HXA006JBZZ	Thermistor	1	AK
2-15	LBND-A042JBE0	Wire fixing band	3	AC
2-16	QW-VZC366JBE0	Lead wire	1	AD
2-17	PPLT-A300JBEZ	Insulating sheet	1	AF

REF. NO.	PART NO.	DESCRIPTION	Q'TY	CODE
2-18	PPLT-A305JBEZ	Insulating sheet	1	AA
2-19	QW-VZE328JBZZ	Lead wire	1	AH

CYCLE PARTS

3- 1	PCMPRA368JBEZ	Compressor	1	CB
3- 2	PCON-A483JBEZ	Condenser	1	BP
3- 3	PEVA-A465JBEZ	Evaporator	1	BN
3- 4	DCPY-A277JBKZ	Capillary tube ass'y	1	AX
3- 5	RHOG-A130JBE0	Overload relay	1	AW
3- 6	PSEL-A150JBE0	Gasket washer	1	AA
3- 7	CPIP-A020JBKZ	Suction tube ass'y	1	AX
3- 8	PPIPCF687JB1Z	Lead tube	1	AF
3- 9	PPIPCF714JB1Z	Discharge tube	1	AR
3-10	GLEG-A073JBE0	Compressor cushion	3	AD
3-11	MSPR-A005JBE0	Protector spring	1	AB
3-12	PCOV-A002JBE0	Terminal cover	1	AE
3-13	PSEL-A006JBE0	Terminal gasket	1	AC

ACCESSORY PARTS

4- 1	TINSEA318JBRZ	Operation manual	1	AD
4- 2	DX-BZA016JBK0	Screws kit	1	AW
4- 3	SSAKAA018YDE0	Bag	1	AB
4- 4	XCTSD40P10000	Tapping screw	6	AA
4- 5	XMPSD40P25000	Wood screw	7	AA
4- 6	LANGAA030JBTA	Base pan angle	2	AD
4- 7	PSEL-A351JBE0	Window insulator	1	AB
4- 8	PSEL-A931JBE0	Window insulator	1	AH
4- 9	PSEL-A932JBE0	Window insulator	1	AE
4-10	TCAD-A351JBEZ	Consumer card	1	AB
4-11	SPADBB452YDE0	Cardboard	1	AD
4-12	SSAKHA246YDE0	Bag	1	AH
4-13	CRMC-A570JBEZ	Remote control	1	AU
4-14	LHLD-A389JBFB	Controller holder	1	AC
4-15	PPLTPA016JBFB	Closure	2	AK
4-16	UBATAA002KKE0	Battery pack	1	AF
4-17	CFZK-B976JBKZ	Closure ass'y	1	BC
4-18	LANGAA011JBFE	Left closure frame	1	AH
4-19	LANGAA012JBFE	Right closure frame	1	AH

PACKING PARTS

5- 1	DPADBA006JBFBZ	Top pad ass'y	1	AK
5- 2	CPADBA052JBKZ	Bottom pad ass'y	1	AP
5- 3	SPAKCB051JBEZ	Packing case	1	AQ
5- 4	SSAKHA245YDE0	Protect	1	AB
5- 5	SSAKAA053YDE0	Bag	1	AB
5- 6	SPAD-A076JBEZ	Comp holder HB	2	BA

SCREWS AND NUTS


6- 1	LX-NZA002JBE0	Special nut	1	AA
6- 2	LX-BZA236JBE0	Special screw	1	AC
6- 3	XTPSD40P08000	Tapping screw	3	AA
6- 4	XHTSD40P10000	Tap tight screw	5	AA
6- 5	XHTSD40P08000	Tap tight screw	4	AA
6- 6	XBPSD40P12J00	Machine screw	2	AB
6- 7	LX-BZA140JBE0	Special screw	4	AB
6- 8	LX-BZ0107CBE0	Special screw	1	AB
6- 9	LX-CZA038WRE0	Special screw	4	AB
6-10	LX-NZA026JBE0	Special nut	3	AC
6-11	LX-NZA074JBE0	Special nut	1	AB
6-12	XCTSD40P06000	Tapping screw	2	AA
6-13	XCTWJ40P16000	Tapping screw	2	AA
6-14	LX-BZA172JBE0	Special screw	3	AB
6-15	XTTSD40P10000	Tapping screw	2	AA
6-16	XTTSD40P12000	Tapping screw	3	AA
6-17	XTTSD40P14000	Tapping screw	11	AA
6-18	XTTSD40P20000	Tapping screw	3	AA
6-19	XTPSD40P14000	Tapping screw	2	AA
6-20	XTTSD40P16000	Tapping screw	2	AA


HOW TO ORDER REPLACEMENT PARTS

To have your order filled promptly and correctly, please furnish the following information.


1. MODEL NUMBER 2. REF. NO. 3. PART NO. 4. DESCRIPTION

CABINET PARTS





CYCLE PARTS



SHARP

COPYRIGHT © 2002 BY SHARP CORPORATION

ALL RIGHTS RESERVED.

No part of this publication may be reproduced, stored in retrieval systems, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of the publisher.